



Pitching Instructions – Shelter

- Assemble the 2 steel upright poles from the sections provided.
- Insert the spike at the top of the pole, through the eyelet, at the front of the shelter, (beside a webbing loop).
- Start by inserting one pole and pegging out in required position, using the supplied double guyline.
- Insert second pole and again peg this in position.
- Attach, and peg out remaining guy lines so that the shelter is free standing.
- The shelter has extra eyelets to allow it to be adapted, and guyed, to your requirements. Additional poles can also be used to open up the sides of the canopy.

Caution:

The shelter is not designed for high wind speeds or exposed campsites.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.
UK Consumer Hotline: 0844 811 0535 E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.